

# CV7

## ULTRASONIC WIND SENSOR


Based on the world recognised ROWIND series, the new modernised ultrasonic wind sensor

CV7

is lighter, compact and has a small consumption. Configurable, it is adapted to the specific constraints of sailboats.

The sensor can be combined with a PC, either with normalised NMEA® input equipment or with any specialised equipment having common interface.

In PC mode, this bi-directional sensor can be programmed and configured for : angle correction, smoothing time constants, measurements units and interface formats.





### Principle of operation: how the equipment works


The sound, the ultrasonic sound is conveyed by the movement of the fluid in which it crosses. The electroacoustic transducers communicate between themselves two by two by ultrasonic signals to determine, following the orthogonal axes, the wave transit time differences induced by the air flow.

The measurements are combined in an integrated calculator in order to establish the wind module and its direction in relation to a reference axis. The temperature measurements are used for calibration corrections.

CV7 Transducers communicate between themselves delivering four independent measures while head wind measured vectors are preferably used for calculations.

This method gives a sensibility of 0.25 knots, a dynamic of 80 knots and an excellent linearity.

The effect of an inclination of the wind sensor is partially corrected due to the shape given by the space.



### Characteristics

Numerical output signals: NMEA0183<sup>®</sup>, MWV, XDR or specialised program.

Wind sensor sensibility: 0,25 knots

Resolution: 0,1 knots

Wind sensor range: 0,25 to 80 knots

Directional sensibility: +/- 1 degree

Resolution: 1 degree

Power supply: 10 to 14 V DC 12 mA

Temperature range: -10 to 55 ° C

Weather proofing: IP67

Weight of the head: 150 g (including the support and clamp: 230g)

### Programmable parameters:

Angle correction in degrees

Smoothing time constant of speed and direction: 1, 2, 4, 8, 16 s

Speed units in knots, m/sec, km/h

Temperature units Centigrade or Fahrenheit

NMEA<sup>®</sup> interface formats or specialised programs.

### Optional accessories:

ST option: compatible with ST40, ST60

BG option: compatible with network, Hydra, Hercule

FI30, FI50, SIL, options

BARO option: measurement of the atmospheric pressure

StatFixBaro : CV7 software program

Vertical fixation adaptor for CV7

Numerical transmission speeds 4 800 or 38 400 baud / sec



EN 55022 EN 55024

### Delivery contents:


CV7 sensor

Support and clamp

25 m cable, 4 conductors

User's notice

CV7 Software configuration





## **Summary**

Installation

NMEA 0183 Interconnexions

FI50 (FI501) Interconnexions

FI30 interconnexions «WIND DATA Instrument»

«FI30 SERVER» Interconnexions

Rowind7 configuration

Piercing gauge

## **Installation**



Determine a place free from obstacles to the wind, generally at the top of the mast.  
 Direct the stirrup of fixation so that Rowind7 is steered forward to the ship.  
 Fix the stirrup following the drillings defined by the joined size.  
 A better precision of the axis can be obtained by using the program of correction of angle.  
 Make the cable walk up to the place reserved for the billposter.  
 Avoid as possible the nearness of cables susceptible to make radio interferences of strong levels.

### **NMEA 0183 Interconnexions**

Red cable	+ Power source
Blue cable	- Power source
Yellow cable	+ NMEA
Green cable	- NMEA


Link the 12 V power source (10 to 14 VDC). Blue cable - / red cable +  
 Connect the receiving display to the connector NMEA :

#### **- For a RS232 computer COM(1) entry**

Link + NMEA to COM1 Rx Terminal 2

Link 0V to 0V the COM1 Terminal 5

If it's necessary, link together the COM1 Terminals 6 and 7.




SUBD 9 COM1 points  
 PC plug  
 Soldering joint side

#### **- For a normalised floating RS422 NMEA 183 entry**

Make sure that none of the entries of the receiver is not connected with the 0 volts, otherwise to apply the typical connection RS232.

Connect + NMEA with (following the naming) +Ve or In + or A of the indicator NMEA


Connect - NMEA with (following the naming) -Ve or In - or B of the indicator NMEA




Example of message:

```
$IIMWV,226.0,R,000.00,N,A*0B
$WIXDR,C,036.5,C,,*52
$PLCJ,75FA,7DEA,03,,,6D7C,837E
$PLCJEAC90,D35D,3F00,2161,FF
```


### **FI50 (Fi501) Interconnexions**



### FI30 interconnexions «WIND DATA Instrument»



### «FI30 SERVER» Interconnexions



### Rowind7 configuration



Rowind7 is delivered with the following configuration :

FI50 Analogical voltage for FI50

Filtering: 2 s

Forces of wind unity : Nds


Temperature unity: °C

Adjustment of the angle of the wind: 0°

To choose other parameters, use the downloadable software on this website:

[www.lcicapteurs.com](http://www.lcicapteurs.com). « Configuration\_CV7 ».

Realise the following connexions:



Decompress the file in the directory of your choice, copy the shortcut to the office.


Double click the shortcut, choose the used serial port.

Put under stress Rowind7

Make the configuration by clicking the corresponding buttons.

Click the button " Programmation CV7 "

Follow the instructions in the screen to put the Rowind7 out of tension and to restart.



Piercing gauge

